


BOOSTER B FORCE BKP SIZE CHART



SIZE	A (CM)	B (CM)
S	42	32
M	44	34
L	46	36

- (A) Upper Leg Circumference:** Measure total circumference of upper leg at its widest point, approx. 10cm from middle of knee.
- (B) Lower Leg Circumference:** Measure total circumference of lower leg / calf at its widest point, approx. 15cm from middle of knee.

Please note : The size chart is only a recommendation. Whether you choose a tight, regular, or loose fit depends entirely on your own personal preference.